

OPERATION MANUAL 取扱説明書

SPECIFICATIONS 仕様

JAMMA STANDARD JAMMA 規格

HORIZONTAL SCREEN ヨコ画面 **POWER SUPPLY**

電源


+5V.....5A


−5V······1A −12V·····1A

Caution ● Adjust to exact +5V on the board.

Make sure to connect −5V.

☆注意:+5VはPCB上で調整して下さい。 ー5Vは必ず配線して下さい。





● 3P CONNECTOR 3Pコネクター

1	3P UP
2	3P DOWN
3	3P LEFT
4	3P RIGHT
5	3P PUSH 1
6	3P PUSH 2
7	
8	COIN 3
9	GND
10	GND

● 4P CONNECTOR 4Pコネクター

1	4P UP
2	4P DOWN
3	4P LEFT
4	4P RIGHT
5	4P PUSH 1
6	4P PUSH 2
7	
8	COIN 4
9	3P START
10	4P START

Edge Connector Cエッジコネクター JAMMA Standard

		r	
SOLDER SIDE(半田面)	NO	NO	PARTS SIDE(部品面)
GND	Α	1	GND
GND	В	2	GND
+5V	С	3	+ 5V
+5V	Ď	4	+ 5y
-5V	E	5	-5V
+12V	F	6	+12V
	H	7	
COIN COUNTER 2	J	8	COIN COUNTER 1
	K	9	
SPEAKER(-)	L	10	SPEAKER(+)
	М	11	
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	P	13	VIDEO BLUE
SERVICE SW	R	14	VIDEO GND
	S	15	
COIN IN 2	Т	16	COIN IN 1
2P START	U	17	1P START
2P UP	٧	18	1P UP
2P DOWN	W	19	1P DOWN
2P LEFT	Х	20	1P LEFT
2P RIGHT	Y	21	1P RIGHT
2P PUSH 1	Z	22	1P PUSH 1
2P PUSH 2	а	23	1P PUSH 2
	b	24	1
	С	25	
	d	26	
GND	е	27	GND
GND	f	28	GND
			

HEATED BARREL" DIP SWITCH SETTINGS

DIP SWITCH "1"			1 1	2	3	4	5_	6	7	8	
	COIN MODE 1		off					C-112-E00-1-12-1-12-1-12-1-12-1-12-1-12-1			
COIN MODE SELECT		SELECT	COIN MODE 2	on							
			1coin 1credit	off	off	off	off	off			
			2coins 1credit	A	on	off	off	off			
ç			3coins 1 credit		off	on	off	off			
Ĭ			4coins 1 credit		on	on	off	off			
N :			5coins 1 credit		off	off	on	off			l
М			6coins 1 credit		on	off	on	off			
O ĐE			1 coin 2 credits		off	on	on	off			
뒫	14005		1 com Scredits		on	on	on	off			
_	MODE 1		1 coin 4 credits		off	off	off	on			
			1 coin 5 credits		on	off	off	on			
			1 coin 6 credits		off	on	off	on			
		2coins 3credits		on	on	off	on				
		3coins 2credits		off	off	on	on				
			5coins 3credits		on	off	on	on			
			8coins 3credits	.	off	on	on	on			
	}	FREE PLAY	off	on	on	on	on				
	COIN A MODE 2 COIN B		1coin 1credit	on	off	off					
7		COIN A	2coins 1 credit	A	on	off					
コイン		COIN A	3coins 1 credit		off	on					
			5coins 1 credit		on	on					
λ—rH		1 coin 2 credits				off	off				
		1 coin 3 credits				on	off				
'`		1 coin 5 credits	! ♦			off	on				
			1 coin 6 credits	on			on	on			
			2p cabi 1 slot	1					off	off	
			4p cabi 1 slot						on	off	
	CABINET SETTING		* 4p (2px2) 1-4 slots						off	on	
	筐体形	式	4p 4 slots 1 for each						on	on	
	SCREEM	FLIP	NORMAL								off
	両面反	\$ \overline{\pi_1}	INVERT								on

^{**}Two 2-player cabinets can be linked together to use it for a 4-player cabinet. 2人用筐体2台をつないで、4人用として使えます。

DIP SWITCH "2"		1	2	3	4	5	6	7	8
NO. of LIVES ライフ	3	off	off						
	1	on	off						
	2	off	on						
	5	on	on						
START & JOIN COIN ゲーム開始時のクレジット	NORMAL			off	off				
	Start x 2 Join x 1			on	off				
	Start x 2 Join x 2			off	on				
	Start x 1 Join x 2			on	on			l ,	
	NORMAL					off	off		
DIFFICULTY	EASY					on	off		
難易度	HARD					off	on		
	VERY HARD					on	on		
CONTINUE PLAY コンティニュー	YES				1			off	
	NO							on	
DEMONSTRATION SOUND	YES		1	, , , , ,				1	off
デモプレー中のサウンド	NO				1				on



TAD CORPORATION

3-31-2 Shimorenjaku, Mitaka, Tokyo "181", Japan Phone: 81-422-42-8031 FAX: 81-422-42-8032

〒181 東京都三鷹市下連雀3-31-2 Phone: 0422-42-8031 FAX: 0422-42-8032